




LIGHT

LIG040..

LIG041..




LIG047..

LIG048..




1

Montaggio
Assembly





MIN - MAX



OK




2




040..
041..

047..
048..



3



040..
041..




MAX 35


Ø MIN 38,5
Ø mAX 42

Ø MIN 28
Ø MAX 42

Ø MIN 28
Ø MAX 42



047..
048..



MAX 35



Ø 50

Ø MIN 28
Ø MAX 42

Ø MIN 28
Ø MAX 42


047..
048..

040..
041..




4


a




b



M Manutenzione Service




D Deviatore Diverter







Sostituzione Cartuccia How to replace Cartridge

040.. 047..
041.. 048..



Sostituzione Deviatore How to replace Diverter



Sostituzione Aeratore How to replace Aerator