



Поз	Наименование детали		
1	top cover	36	bridge axis pulley
2	frame	37	lower retaining ring of bridge axis
3	back cover	38	vice motor pulley
4	main motor pulley	39	vice motor
5	main motor	40	vice motor block
6	top bearing block	41	circlip for shaft
7	bearing	42	circlip for shaft
8	shaft wheel	43	motor seat pin shaft
9	round nut	44	motor seat adjusting screw
10	lock washer	45	keyway transfer pin
11	bearing	46	Movable cover limit block
12	spiral shaft	47	travel switch press wheel
13	lower bearing block	48	keyway free transfer pin
14	dust ring	49	travel switch
15	sprial	50	sticker
16	fix rod	51	power light
17	protective cover	52	stop button
18	fixed hood	53	timer
19	bowl	54	change-over switch
20	up retaining ring for lower shaft	55	start button
21	flange for lower shaft		
22	lower shaft		
23	oil seal		
24	bearing		
25	lower bearing block		
26	bearing		
27	circlip for hole		
28	circlip for shaft		
29	lower shaft sprocket		
30	retaining ring for lower shaft		
31	retaining ring for bridge axis		
32	bearing		
33	lower bridge axis		
34	bearing		
35	bridge bearing shock		