


No.	Name
1	Handle
2	Heating Tube
3	Top Cover
4	Cover Screw
5	Cover Hinge
6	M6X8
7	M6X35
8	Rotating Screw
9	M6 Screw
10	M10X8
11	Cable
12	Plug
13	S/S plate
14	S/S plate
15	Down cover Rotating
16	M10x25
17	Plate Fixer
18	Timer
19	Frame Sealing Plate
20	Rubber Pad
21	Timer Knob
22	Frame
23	Temperature Dial
24	Temperature Knob
25	Temperature Control
26	Switch
27	Indicator Light
28	Srew M10
29	Insulating Plate
30	Waffle Fitting Plate
31	Down Waffle Plate
32	Upper Waffle Plate



- 1 Srew M10
- 2 M6X8
- 3 Cover Hinge
- 4 Cable
- 5 Plug
- 6 S/S plate
- 7 M6X35
- 8 Down cover Rotating
- 9 Rubber Pad
- 10 Timer
- 11 Timer Knob
- 12 Plate Fixer
- 13 Frame Sealing Plate
- 14 Temperature Knob
- 15 Temperature Control
- 16 Indicator Light
- 17 Switch
- 18 Temperature Dial
- 19 Frame
- 20 M10
- 21 Insulating Plate
- 22 Waffle Fitting Plate
- 23 Heating Tube
- 24 Down Waffle Plate
- 25 M6
- 26 Rotating Screw
- 27 M10
- 28 S/S plate
- 29 Handle
- 30 Cover
- 31 Upper Waffle Plate