

Blixer® 2 / 3 / 4 / 4 V.V.

Consignes de sécurité et d'utilisation / Safety and Operating Instructions
 Veiligheidsvoorschriften en gebruiksaanwijzing / Sicherheits- und Bedienungshinweise

À fixer au mur.
 Hang on the wall.
 Aan de wand te bevestigen.
 An der Wand zu befestigen.




robot coupe®
 www.robot-coupe.com


Tableau de commande / Control Panel / Bedieningspaneel / Bedienfeld




Mise en marche et utilisation / Switching on and using the mixer / Inwerkingstelling en gebruik / Inbetriebnahme und Bedienung




Nettoyage et entretien / Cleaning and maintenance / Reiniging en onderhoud / Reinigung und Wartung




Cuve / Bowl / Kuip / Schüssel





BLIXER 3 / 4 Couteau / Blade / Mes / Messer



Bague d'étanchéité / O-ring (seal) / Afdichtingsring / Dichtungsring



Sécurité / Safety / Veiligheid / Sicherheit



Blixer® 2 / 3 / 4 / 4 V.V.

Consignas de seguridad y empleo / Instruções de segurança e de utilização

Istruzioni di sicurezza e d' utilizzo / Техника безопасности и руководство по эксплуатации

Fijación mural.
Para afixar na parede.
Da fissare a parete.
Повесить на стену.



robot coupe®

www.robot-coupe.com

Panel de mandos / Painel de controlo / Quadro comandi / Панель управления



Botón Parada
Botão Desligar
Pulsante arresto
Кнопка «Стоп»



Botón Marcha
Botão Ligar
Pulsante accensione
Кнопка «Пуск»



Botón Pulse
Botão Pulse
Pulsante impulsi
Кнопка «Пульс»




Blixer 4 Selector de velocidad
Blixer 4 Seletor de velocidade
Blixer 4 – Selettore di velocità
Blixer 4 Переключатель скорости




Blixer 4 V.V. Variador de velocidades
Blixer 4 V.V. Variador de velocidade
Blixer 4 V.V. – Variatore di velocità
Blixer 4 V.V. Регулятор скорости


Puesta en marcha y utilización / Ligaço e utilização / Accensione e utilizzo / Включение и использование



Limpeza y mantenimiento / Limpeza e manutenção / Pulizia e manutenzione / Чистка и уход




Cuba / Cuba / Vasca / Чаша




BLIXER 3 / 4




Cuchilla / Lâmina / Coltello / Нож



Anillo de hermeticidad / Anel de vedação / Anello di tenuta / Уплотнительное кольцо



Seguridad / Segurança / Sicurezza / Безопасность



! Nunca tratar de suprimir los sistemas de bloqueo y de seguridad.
Nunca tentar suprimir os sistemas de bloqueio e de segurança.
Non cercare in alcun caso di eliminare i sistemi di blocco di sicurezza.
Никогда не отключать системы блокировки и защиты.