

## HWH-15B CE SPARE PART LIST

S/N	NAME	SPECIFICATION	MATERIAL	QUANTITY	S/N	NAME	SPECIFICATION	MATERIAL	QUANTITY
1	right cover board	BMW30-02-03	1Cr18Ni9T	1	22	bearing		6206	2
2	bowl	BMW30-01-11	1Cr18Ni9T	1	23	oil seal		32x52x8	4
3	red and green switch			1	24	crossing bridge shaft	BMW25-01-04	45#	1
4	top cover	BMW30-02-04	1Cr18Ni9T	1	25	small sprocket	BMW30-01-03	45#	1
5	flat key		8x32	2	26	bearing base		UCP205	2
6	main shaft	BMW25-01-07	2Cr13	1	27	intermediate bottum	BMW30-02-06	1Cr18Ni9T	1
7	nut		M10	3	28	hexagon screw		M10X40	4
8	hexagon screw		M10X25	3	29	flat washer		10	4
9	stirring hook	BMW30-01-12-00	1Cr18Ni9T	1	30	spring washer		40	4
10	hexagon screw		M10X40	4	31	nut		M10	4
11	flat washer		10	4	32	big belt pulley	YMZD350-02	HT200	1
12	spring washer		10	4	33	triangle belt		A1092	2
13	nut		M10	4	34	rear panel	BMW30-02-05	1Cr18Ni9T	1
14	main bearing base	BMW15-01-08	HT200	1	35	left cover board	BMW30-02-02	1Cr18Ni9T	1
15	bowl support base	BMW25-01-09	HT200	1	36	body frame	BMW30-02-01-00		1
16	bowl flange	BMW25-01-10	HT200	1	37	motor			1
17	big sprocket	BMW30-01-06	45#	1	38	small belt pulley	YMZD350-01	HT200	1
18	chain		100section 06B-2	2	39	flat key		8X32	1
19	shaft circlip		30	2	40	nut		M10X45	1
20	hole circlip		53	2	41	flat washer		10	1
21	countersink screw		M8X20	8	42	hexagon screw		M10	1