
ФРИТЮРНИЦА STARFOOD FRI-4LA





ФРИТЮРНИЦА STARFOOD FRI-4LA

| 1 | Power line |
|----|-----------------------------------|
| 2 | Cover of electric box |
| 3 | Ceramic connector |
| 4 | Safety switch |
| 5 | Electric box |
| 6 | Hanging for basket |
| 7 | Protect board for heating element |
| 8 | Thermostat |
| 9 | Heating tube |
| 10 | Oil pot 4L |
| 11 | frame |
| 12 | Handle of frame |
| 13 | Rubber feet |
| 14 | Layer of frying basket |
| 15 | Frying basket+handle |
| 16 | Cover of oil pot |
| 17 | Handle of cover |
| 18 | Switch knob |
| 19 | Indicate light |
| 20 | Main switch |
| 21 | Temperature limiter |

